

# POWER ENGINEERING

#06 THREE-PHASE AC POWER SYSTEMS POWER MEASUREMENT (1)

2018




# Power Measurement in Three Phase AC Systems

#### Today we will investigate:

- Balanced DELTA connected load (Summary + Example)
- Load Phase power and Supply Power
- Power Measurement #1: 3 Wattmeter Method
- Power Measurement #2: 2 Wattmeter Method
- Unbalanced DELTA connected load


#### **Balanced Delta Connected Load:**




#### **Reminders:**

- 1. Line Voltages (eg  $V_{RY}$ ) are  $\sqrt{3}x$  Phase Voltages (eg  $V_{RN}$ ) and LEAD the phase voltages by  $30^\circ$
- 2. Line Currents (eg  $I_R$ ) are  $\sqrt{3}x$  Load Phase Currents (eg  $I_{RY}$ ) and LAG the phase currents by  $30^\circ$

## **Balanced Delta Connected Load: Phasor Diagram**




#### **Balanced Delta Connected Example**



For the balanced 3 phase Delta connected load determine the following:


- 1. The magnitude of the line voltages
- 2. The line currents  $I_R$ ,  $I_Y$  and  $I_B$
- 3. The phasor diagram showing all currents and voltages
- 4. The TOTAL real power supplied by the 3 phase supply

#### Load Phase $(Z_{RY})$ Real Power (W):



Remember: the real power (W) output in a complex impedance is equal to the magnitude of the voltage across the impedance multiplied by the magnitude of the current through the impedance multiplied by the Cosine of the angle between that voltage and current (set by the load impedance)

#### **Supply (V<sub>RN</sub>) Real Power (W):**



Now assuming no loss in the transmission lines then the Supply Power should equal the Load Phase Power

Note: Angle between  $V_{RY}$  and  $I_R = 30^{\circ} + \Phi_1$ 

$$P_{RN} = |V_{RN}|.|I_R|.Cos\Phi_1 = P_{RY} = |V_{RY}|.|I_{RY}|.Cos\Phi_1$$

Proof: 
$$V_{RN}.I_R.Cos\phi_1 = \frac{V_{RY}}{\sqrt{3}}.\sqrt{3}.I_{RY}.Cos\phi_1$$

 $V_{RN}.I_{R}.Cos\phi_1 = V_{RY}.I_{RY}.Cos\phi_1$ 



### **Total Real Power in Balanced 3 Phase System:**

$$P_T = 3.|V_{ph}|.|I_L|.Cos\Phi$$

respective line current

$$P_T = 3.|V_L|.|I_{ph}|.Cos\Phi$$

Where Φ is angle between line voltage and respective load phase current


Where Φ is angle between

phase voltage and

Where I<sub>1</sub> and V<sub>1</sub> are line current and voltage respectively

#### **Power Measurements in 3 Phase Systems:**






# 'Classic' Wattmeter Measures: Voltage (V) Current (A) Power Factor (angle between voltage and current)

#### Power Measurement #1: 3 Wattmeter Method


# 3-phase 3-wire



Wattmeter 1:  $V_{W1}$ ,  $A_{W1}$ , &  $\Phi_{W1}$ 

Wattmeter 2:  $V_{W2}$ ,  $A_{W2}$ , &  $\Phi_{W2}$ 


Wattmeter 3:  $V_{W3}$ ,  $A_{W3}$  &  $\Phi_{W3}$ 



Note: Φ set by load impedance

#### Power Measurement #2: 2 Wattmeter Method

# 3-phase 3-wire




$$P_{W1} = |V_{RB}|.|I_R|.Cos\Phi_{W1}$$

Where  $\Phi_{W1}$  = angle between  $V_{RB}$  and  $I_{R}$ 

$$P_{W2} = |V_{YB}|.|I_{Y}|.Cos\Phi_{W2}$$

Where  $\Phi_{W2}$  = angle between  $V_{YB}$  and  $I_{Y}$ 



Note:  $\Phi$  set by load impedance and  $Cos\Phi = PF$ 

$$P_{Total} = P_{W1} + P_{W2} = |V_{RB}|.|I_{R}|.Cos\Phi_{W1} + |V_{YB}|.|I_{Y}|.Cos\Phi_{W2}$$

Substitute for  $\Phi_{W1}$  and  $\Phi_{W2}$  and solve:

#### Equations solved on whiteboard

# Result (for a balanced load):

$$P_{Total} = 3.|V_{ph}|.|I_L|.Cos\Phi$$

Note: You will get the chance to prove the application of the 2 Wattmeter method to a balanced STAR connected load as part of the 3 Phase Tutorial.

Note: Φ set by load impedance

#### **Modern Digital Sampling Power Meters/Analysers:**




#### Manufacturers:

Voltech

Fluke

Yokagawa



$$Power(W) = \frac{1}{N} \sum_{i=0}^{N} v.i$$

where N is the number of samples in a period


— Voltage — Current — Power

#### We now need to turn our attention to **UNBALANCED** Load Conditions:

- Unbalanced DELTA connected load
- Unbalanced 3 wire STAR connected load
- Unbalanced 4 wire STAR connected load

The plan is to outline the necessary steps to solve for each of the unbalanced conditions and then to highlight these with some examples (this and next lecture)

#### **Unbalanced DELTA Connected Load:**



For the Unbalanced load:  $Z_{RY} \neq Z_{YB} \neq Z_{BR}$ 

Therefore:  $I_{RY} \neq I_{YB} \neq I_{BR} \& I_{R} \neq I_{Y} \neq I_{B}$ 

#### Solution:

Calculate individual load phase currents: Step 1:

$$I_{RY} = \frac{V_{RY}}{Z_{RY}}$$
 
$$I_{YB} = \frac{V_{YB}}{Z_{YB}}$$
 
$$I_{BR} = \frac{V_{BR}}{Z_{BR}}$$

$$I_{YB} = \frac{V_{YB}}{Z_{YB}}$$

$$I_{BR} = \frac{V_{BR}}{Z_{BR}}$$

Step 2: Calculate individual line currents:

$$I_R = I_{RY} - I_{BR}$$


$$I_R = I_{RY} - I_{BR}$$
  $I_Y = I_{YB} - I_{RY}$   $I_B = I_{BR} - I_{YB}$ 

$$I_B = I_{BR} - I_{YB}$$

Step 3: Calculate Total Real Power:

$$P_{T} = |V_{RY}|.|I_{RY}|.Cos\Phi_{RY} + |V_{YB}|.|I_{YB}|.Cos\Phi_{YB} + |V_{BR}|.|I_{BR}|.Cos\Phi_{BR}$$

#### **Unbalanced Delta connected load example:**



#### Determine:

- 1] All the load phase currents
- 2] Draw a phasor diagram (to scale) showing all line voltages and load phase currents. From this estimate the line currents.
- 3] The total 3 phase power (W) at the load

#### **Solution done on Whiteboard**